

EE16A Imaging 3




Announcements

- Buffer Week Schedule on Piazza
 - Can make up any Imaging Lab (1, 2, or 3)
- Midterm 10/1 - study hard!
- This lab is conceptually very challenging
 - This presentation will help a lot :)
 - Also, there's a homework problem that is quite similar



Last week: Single-Pixel Scanning



- Setup a masking matrix where each row is a mask
 - Measured each pixel individually once

Last Week: SPS is Matrix-Vector Multiplication

1	0	0	0	0	0	0	0	...
0	1	0	0	0	0	0	0	...
0	0	1	0	0	0	0	0	...
0	0	0	1	0	0	0	0	...
0	0	0	0	1	0	0	0	...
0	0	0	0	0	1	0	0	...
0	0	0	0	0	0	1	0	...
...								

Masking Matrix H


i_1
i_2
i_3
i_n

Unknown,
vectorized
image, \vec{i}


=

s_1
s_2
s_3
s_n

Recorded
Sensor
readings, \vec{s}



Last week: Single-Pixel Scanning




- Setup a masking matrix where each row is a mask
 - Measured each pixel individually once
- **How can we reconstruct our scanned image?**
- **What are the requirements of our masking matrix H?**


$$\vec{s} = H\vec{i}$$

- Are all invertible matrices equally good as scanning matrices?
- What happens if we mess up a single scan?

Today: Multi-Pixel Scanning



- **Can we measure multiple pixels at a time?**
 - Measurements are now linear combinations of pixels
- **How can we reconstruct our scanned image? Why?**
 - But there are still other things to be concerned about



- We want to improve the quality of our images
- Fountain codes homework
 - The idea was good enough to get Qualcomm to buy the inventors' company
- Redundancy is always good
 - Averaging measurements is better than just keeping bad values

- We need to change our masks to improve our SNR (signal to noise ratio)
 - Take smarter measurements
 - Measure linear combinations of pixels instead of a single pixel
 - Redundancy is key to getting good results
- Problems?
 - Our measurements are noisy
 - What is noise?
 - Noise can be amplified through inverting a matrix
 - How?

What is noise?


0
1
2
.
.
.
10

Let's say we expect this from our sensor
But instead we get this



0.4
0.95
2.1
.
.
.
9.8





What is Noise?

0.4
0.95
2.1
.
.
.
9.8

\vec{s}_{real}

We can say that this vector is the ideal vector plus some vector of disturbances we call “noise,” represented by ω

=

0
1
2
.
.
.
10

\vec{s}_{ideal}

+

0.4
-0.05
0.1
.
.
.
-0.2

$\vec{\omega}$

The Missing Link

- H Is an NxN matrix that we know is linearly independent (invertible).

Therefore:

- H has N linearly independent eigenvectors
- N lin. ind. vectors can span \mathbb{R}^N
 - They span the noise vector

- The inverse has eigenvalues $\frac{1}{\lambda_1}, \frac{1}{\lambda_2}, \dots, \frac{1}{\lambda_n}$



The Missing Link

Thus the noise term from before can be written as:


$$\vec{\omega} = \alpha_1 \vec{v}_1 + \alpha_2 \vec{v}_2 + \cdots \alpha_n \vec{v}_n$$

And:

$$H^{-1} \vec{\omega} = H^{-1} (\alpha_1 \vec{v}_1 + \alpha_2 \vec{v}_2 + \cdots \alpha_n \vec{v}_n)$$

Finally


$$= \frac{1}{\lambda_1} \alpha_1 \vec{v}_1 + \frac{1}{\lambda_2} \alpha_2 \vec{v}_2 + \cdots \frac{1}{\lambda_n} \alpha_n \vec{v}_n$$




Linking it all together

$$\vec{l}_{est} = H^{-1}\vec{s} + \boxed{H^{-1}\vec{\omega}}$$
$$\boxed{H^{-1}\vec{\omega}} = \frac{1}{\lambda_1}\alpha_1\vec{v}_1 + \frac{1}{\lambda_2}\alpha_2\vec{v}_2 + \dots \frac{1}{\lambda_n}\alpha_n\vec{v}_n$$


- The noise is directly related to the eigenvalues.
- We don't know what the alphas are, but we can reduce noise by choosing good eigenvalues
 - **What are good eigenvalues?**
- **What properties would a good H matrix have?**






Possible Scanning Matrix: Random


Mask 0: 272.0 Illuminated Pixels




Mask 1: 281.0 Illuminated Pixels



Mask 2: 313.0 Illuminated Pixels



Mask 3: 289.0 Illuminated Pixels



- Illuminate ~300 pixels per scan
 - Usually invertible
 - But what are its eigenvalues?


(ツ)





A more systematic scanning matrix:

- Hadamard matrix!
- Constructed to have large eigenvalues
 - Just what we need!



Notes



- READ CAREFULLY - Very long lab with lots of reading; heavily tests understanding of eigen stuff
- Post check off link is optional but very cool
- Can adjust projector settings
 - Focus with dial on side
 - Brightness, contrast, sharpness
- If you aren't checked off for Imaging 2, do so today

